



WHEEL BAND STEP BY STEP INSTRUCTION GUIDE

1. Ensure the wheel has a 4mm flat surface around the entire wheel edge or rim.
2. Determine the size of the wheel and choose the corresponding size mounting track and band insert.
3. Clean the wheel with a wax and grease remover. Apply wax and grease remover to one towel and clean a 3 inch area starting at the wheel edge or rim. Immediately wipe off the wax and grease remove with a clean dry towel. Repeat if the wheel has excessive amounts of tire dressing or silicone.
4. Clean the same area with a towel saturated with rubbing alcohol. Ensure mounting surface is clean by using a clean white towel. Repeat cleaning with rubbing alcohol if necessary.
5. Visually inspect the lead edge of the mounting track to ensure a flush seam. Trim the lead edge of the mounting track if necessary.
6. Remove 2 inches of the adhesive backing to reveal the adhesive.
7. Attach mounting track to the edge making sure the edge of the mounting track is flush with the edge of the wheel.
8. Continue to remove backing in 2 inch increments and lightly attach the mounting track to the wheel. In case of improper placement, lift mounting track directly toward you and replace in proper location.
9. Upon reaching the starting point, leave the remaining backing on the track. Visually line up the end of the track with the lead edge and score or mark the end of the track.
10. Cut the end of the mounting track as straight as possible. Remove the remaining adhesive backing and secure the end of the track flush with the lead edge.
11. Visually inspect the lead edge of the insert band to ensure a flush seam. Trim the lead edge of the insert band if necessary.
12. Snap the insert band in the mounting track starting directly opposite of the mounting track seam. Before inserting the last 2 inches of the insert, score or mark the end of the insert.
13. Cut the end of the band insert and secure the last 2 inches starting with the end of the insert.
14. Press firmly to secure the adhesive using the application tool or by hand.
15. Allow adhesive to fully cure for 5 days before washing.